

IC INRUN BENCH ASSEMBLY INSTRUCTIONS



Step 1 take the shelf with the addition 8 holes (that go all the way through)



Step 2 center the shelf on the bottom side of the cushion and screw down with 1 3/4" screws. Be careful not to strip them out



Step 3 install the shelf just like all the others



Step 4 screw the shelf down with 3/4" screws provided